OhGeni

User Guide

PACKAGE CONTENTS

①	Air mattress with built in pump	②	Carrying bag
③	4 × Repair patches	④	User Guide

WARNING

THIS PRODUCT IS NOT FLAME RESISTANT. THIS BED CONTAINS PLASTIC. DO NOT PLACE AIR BED NEAR OPEN FLAME OR ANY OTHER SOURCE OF IGNITION .

1.Unplug or disconnect the appliance from the power supply before use.
2.This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit a polarized outlet in only one way, if the plug does not fully fit the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. Do not tamper with it.
3.Indoor use only. Make sure the surface is clean of any debris, sharp objects, or protrusions and place bed in a safe area before use. Make sure that there are no sharp edges, steps, drops or breakable items in the nearby. Use it on flat surfaces, as bed would be tipped over on uneven surfaces.
4.Do not run the motor for over 5 minutes. Users should allow the motor to cool down for 5 minutes between uses.
5. The air vent on the cover should be kept free of debris during use.
6. Store in a dry place.
7.Infants have suffocated on inflatable mattresses. Never place an infant(babies up to 15 months) to sleep on this inflatable air mattress/air bed.
8.Children can get entrapped between the inflatable mattress and an adjacent vertical surface such as walls, dressers, etc.
9.Always keep the inflatable mattress fully inflated when in use.
10. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or equally qualified persons in order to avoid a hazard.
11.This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Keep children away from the product when not using it. Maintenance shall be done by capable adults.
12.Do not step or jump on bed, or use as a trampoline. Standing, jumping or walking on the bed may result in injury, damage or puncture the bed.

NOTE: Drawings for illustration purpose only. May not reflect actual product. Not to scale.


SET UP GUIDE

Your air bed has a built in air pump as well as a 2 stage valve, both for optional inflation and deflation.




The valve is composed of three parts:

①Upper cap
②Middle valve with valve lip
③Bleeder valve



Ⓐ 2 Stage Valve Ⓑ Built-in Air Pump Ⓒ Power Cord Storage


VALVE USAGE GUIDELINES




INFLATION

METHOD 1


Step.1




Step.2



Step.3




Step.4




METHOD 2

This air bed comes with a secondary inflate/deflate option (A) for use with portable air pumps as a backup to the installed automatic pump. To use a portable air pump (portable air pump not included) follow these instructions:


Step.1




Step.2




Step.3




Step.4



DEFLATION





FOLDING INSTRUCTIONS

Step.1



Step.2



Step.3



Step.4



Step.5



Step.6




Step.7



Step.8 *Appearance of actual bag may vary



FIRST INFLATION



CARE AND MAINTENANCE

1. Inspect your bed before each use.
2. Keep your bed away from any sharp or protruding objects. Large cuts, tears, or snags may not be repairable and will not be covered by your warranty.
3. When not in use, put the bed in a clean, dry place out of extreme temperatures.

CLEANING

1. DO NOT SUBMERGE MATTRESS IN WATER!
2. For spot cleaning, use a clean damp cloth to wipe the surface of the mattress. Apply a clear liquid dish detergent without dye if necessary.
3. Wet stained area thoroughly gently rub the stained area with detergent. Blot the area to remove the staining substance.
4. Rinse thoroughly and pat dry. Allow your bed to air dry completely after cleaning and before storing.

ADDITIONAL INFORMATION

-IN CASE OF AIR LEAKAGE


Please check the following in case of air leakage:

1. Is the inflate/deflate valve on the built-in pump turned to the inflate position?

2. Is the secondary inflate/deflate valve cap closed?

Repair patches are included for minor repairs.

HOW TO CHECK AIR LEAKAGE AREA




Notice

Check if the valve and pump are closed.



Method 1

Inflate the bed and check for air leaks by hand. The air leak is where you can feel a strong air stream coming out.



Method 2

Inflate the bed and carry it to the yard. Prepare a water faucet or a bucket of water and then slowly pour it over the whole mattress to see where the bubbles come out.



Method 3

Inflate the bed, then dip thick soap foam with a soft brush and evenly smear it on the inflatable bed, one area at a time. If you see big bubbles popping out or hear a squeaking sound, that is where air leaks are formed.


HOW TO FIX LEAKS

METHOD 1: Repair patch (recommended)


Deflate the air mattress and then clean the area around the puncture. Trim the patch to an oval shape and ensure it is big enough to cover the puncture. Pull off the back paper from the patch and then place it over the puncture. Press the patch down firmly and ensure there is no trapped air under it.

METHOD 2:PVC repair (You need to buy it from somewhere else)


NOTE: Please cut off the power before cleaning and finding/repairing holes.




1. Locate the air leakage point， and clean the area with a diameter of 6cm around it.




2. Trim the patches into smaller pieces that are about 1-1.5cm larger than the leak point.




3. Apply glue evenly to the marked puncture and to the patches.



4. Stick patches on the mattress.



5. Leave the glue to dry for 5-10 minutes. Use a hair dryer for a short time to help the glue to dry.



6. Use a flat object to press down on the repair patch. Wait 24 hours before inflating the bed.

WARRANTY INFORMATION

ONE YEAR NON-TRANSFERRABLE LIMITED WARRANTY

To provide customers with quality shopping and user experience, we guarantee to replace or issue a refund or provide acceptable solutions to any defective products (as customers prefer) from the date of purchase to 1 years.

Proof of purchase must be provided (Amazon order number or receipt) when making a claim to our customer support center.

Warranty registration may be requested within a month since the date of purchase, by sending your Amazon order number to the mailbox: support@aborderproducts.com.

The warranty is not transferrable. We only provide warranty services to buyers who purchased from our Amazon store and possess the purchase proof, and not to any other purchaser or subsequent owner.

Price matching policy is not applicable. We do not provide a price difference refund.

Sellers are the responsible party. Amazon allows different sellers to sell the same product, so please confirm the seller by checking the order details before contacting us.

WHAT IS COVERED
1. Received defective or used (proof needed) products;
2. Received with missing parts;
3. Defective item under proper use.

WHAT IS NOT COVERED
1. Purchased from non-Amazon channel or other physical stores;
2. Gift without proof of purchase;
3. Tampering/ abnormal use/ accidental damage;
4. Replacements and parts;
5. Installation fee/ labor fee.

MAKING A CLAIM
If you have any problems when using our products, you can choose any of the methods to reach out to us.

MANUFACTURER SUPPORT

Email:support@aborderproducts.com
30Days Free Return & Replacement
2 - Year Product Warranty

Gifted parts, replacements, consumable products are not covered by the 2-year warranty. Manufacturers' warranties may not apply in all cases, depending on factors such as use of the product, where the product was purchased, or who you purchased the product from. Please review the warranty carefully, and contact the manufacturer if you have any questions.